

GOODWE



User Manual

Grid-Tied PV Inverter

MS Series
(5-10kW) G3

V1.6-2024-03-01

Copyright ©GoodWe Technologies Co., Ltd., 2024. All rights reserved

No part of this manual can be reproduced or transmitted to the public platform in any form or by any means without the prior written authorization of GoodWe Technologies Co., Ltd.

Trademarks

GOODWE and other GOODWE trademarks are trademarks of GoodWe Technologies Co.,Ltd. All other trademarks or registered trademarks mentioned in this manual are owned by GoodWe Technologies Co.,Ltd.

NOTICE

The information in this user manual is subject to change due to product updates or other reasons. This guide cannot replace the product labels or the safety precautions in the user manual unless otherwise specified. All descriptions here are for guidance only.

CONTENT

| | | |
|----------|------------------------------|-----------|
| 1 | About This Manual | 1 |
| 1.1 | Applicable Model | 1 |
| 1.2 | Target Audience | 1 |
| 1.3 | Symbol Definition | 2 |
| 2 | Safety Precaution | 3 |
| 2.1 | General Safety | 3 |
| 2.2 | DC Side | 3 |
| 2.3 | AC Side | 4 |
| 2.4 | Inverter Installation | 4 |
| 2.5 | Personal Requirements | 5 |
| 2.6 | EU Declaration of Conformity | 5 |
| 3 | Product Introduction | 6 |
| 3.1 | Application Scenarios | 6 |
| 3.2 | Circuit Diagram | 6 |
| 3.3 | Supported Grid Types | 6 |
| 3.4 | Features | 7 |
| 3.5 | Appearance | 8 |
| 3.5.1 | Parts | 8 |
| 3.5.2 | Indicators | 9 |
| 3.5.3 | Nameplate | 10 |
| 4 | Check and Storage | 11 |
| 4.1 | Check Before Receiving | 11 |
| 4.2 | Deliverables | 11 |
| 4.3 | Storage | 12 |
| 5 | Installation | 13 |
| 5.1 | Installation Requirements | 13 |
| 5.2 | Inverter Installation | 16 |
| 5.2.1 | Moving the Inverter | 16 |
| 5.2.2 | Installing the Inverter | 16 |
| 6 | Electrical Connection | 18 |
| 6.1 | Safety Precaution | 18 |

| | |
|---|-----------|
| 6.2 Connecting the PE Cable | 19 |
| 6.3 Connecting the PV Input Cable | 19 |
| 6.4 Connecting the AC Output Cable | 22 |
| 6.5 Communication | 26 |
| 6.5.1 Communication Network Introduction | 26 |
| 6.5.2 Communication Port Introduction..... | 28 |
| 6.5.3 DRM Description | 29 |
| 6.5.4 Connecting the Communication Cable (optional)..... | 30 |
| 6.5.5 Installing the Communication Module (optional)..... | 31 |
| 6.5.6 Connecting the USB-RS485 Cable(Optional)..... | 32 |
| 7 Equipment Commissioning | 33 |
| 7.1 Check Before Power ON | 33 |
| 7.2 Power On..... | 33 |
| 8 System Commissioning | 34 |
| 8.1 Indicators and Buttons..... | 34 |
| 8.2 Setting Inverter Parameters via LCD | 35 |
| 8.2.1 LCD Menu Introduction..... | 36 |
| 8.2.2 Inverter Parameter Introduction | 37 |
| 8.3 Upgrading the Firmware | 38 |
| 8.3.1 Upgrading the Firmware Via USB-RS485 Cable..... | 38 |
| 8.3.2 Upgrading the Firmware Via USB Flash Disk..... | 38 |
| 8.4 Setting Inverter Parameters via SolarGo App | 39 |
| 8.5 Monitoring via SEMS Portal | 39 |
| 9 Maintenance | 40 |
| 9.1 Power Off the Inverter..... | 40 |
| 9.2 Removing the Inverter..... | 40 |
| 9.3 Disposing of the Inverter | 40 |
| 9.4 Troubleshooting | 40 |
| 9.5 Routine Maintenance..... | 48 |
| 10 Technical Parameters | 49 |

About This Manual

This manual describes the product information, installation, electrical connection, commissioning, troubleshooting, and maintenance. Read through this manual before installing and operating the product. All the installers and users have to be familiar with the product features, functions, and safety precautions. This manual is subject to update without notice. For more product details and latest documents, visit <https://en.goodwe.com>.

1.1 Applicable Model

This manual applies to the listed inverters below (MS for short):




| Model | Nominal Output Power | Nominal Output Voltage |
|---------------|----------------------|------------------------|
| GW5000-MS-30 | 5kW | 220/230/240V |
| GW6000-MS-30 | 6kW | |
| GW7000-MS-30 | 7kW | |
| GW8500-MS-30 | 8.5kW | |
| GW9900-MS-30 | 9.99kW | |
| GW10K-MS-30 | 10kW | |
| GW7000-MS-C30 | 7kW | 220/230V |
| GW8000-MS-C30 | 8kW | |

1.2 Target Audience

This manual applies to trained and knowledgeable technical professionals. The technical personnel has to be familiar with the product, local standards, and electric systems.

1.3 Symbol Definition

Different levels of warning messages in this manual are defined as follows:

| |
|--|
|  DANGER |
| Indicates a high-level hazard that, if not avoided, will result in death or serious injury. |
|  WARNING |
| Indicates a medium-level hazard that, if not avoided, could result in death or serious injury. |
|  CAUTION |
| Indicates a low-level hazard that, if not avoided, could result in minor or moderate injury. |
| NOTICE |
| Highlight and supplement the texts. Or some skills and methods to solve product-related problems to save time. |

2 Safety Precaution

Notice

The inverters are designed and tested strictly complies with related safety rules. Read and follow all the safety instructions and cautions before any operations. Improper operation might cause personal injury or property damage as the inverters are electrical equipment.

2.1 General Safety

Notice

- The information in this quick installation guide is subject to change due to product updates or other reasons. This guide cannot replace the product labels otherwise specified. All descriptions here are for guidance only.
- Before installations, read through the quick installation guide. For additional information, please see the user manual.
- All operations should be performed by trained and knowledgeable technicians who are familiar with local standards and safety regulations.
- Check the deliverables for correct model, complete contents, and intact appearance. Contact the manufacturer if any damage is found or any component is missing.
- Use insulating tools and wear personal protective equipment when operating the equipment to ensure personal safety. Wear anti-static gloves, clothes, and wrist strip when touching electronic components to protect the inverter from damage. The manufacturer shall not be liable for any damage caused by static electricity.
- Strictly follow the installation, operation, and configuration instructions in this guide and user manual. The manufacturer shall not be liable for equipment damage or personal injury if you do not follow the instructions. For more warranty details, please visit <https://en.goodwe.com/warranty>.

2.2 DC Side


DANGER

Connect the DC cables using the delivered PV connectors. The manufacturer shall not be liable for the equipment damage if other connectors or terminals are used.

WARNING


- Ensure the component frames and the bracket system are securely grounded.
- Ensure the DC cables are connected tightly, securely, and correctly. Inappropriate wiring may cause poor contacts or high impedances, and damage the inverter.
- Measure the DC cable using the multimeter to avoid reverse polarity connection. Also, the voltage should be under the max DC input voltage. The manufacturer shall not be liable for the damage caused by reverse connection and extremely high voltage.
- Do not connect the same PV to multiple inverters. Otherwise, the inverters may be damaged.
- The PV modules used with the inverter must have an IEC61730 class A rating.

2.3 AC Side









 **WARNING**

- The voltage and frequency at the connecting point should meet the on-grid requirements.
- Additional protective devices like circuit breakers or fuses are recommended on the AC side. Specification of the protective device should be at least 1.25 times the maximum output current.
- Make sure that all the groundings are tightly connected.
- You are recommended to use copper cables as AC output cables. If you prefer aluminum cables, remember to use copper to aluminum adapter terminals.

2.4 Inverter Installation

 **DANGER**

- Do not apply mechanical load to the terminals, otherwise the terminals can be damaged.
- All labels and warning marks should be visible after the installation. Do not scrawl, damage, or cover any label on the device.
- Unauthorized dismantling or modification may damage the equipment, the damage is not covered under the warranty.
- Testing to AS/NZS 4777.2:2020 for multiple inverter combinations has not been conducted. So external devices should be used in accordance with the requirements of AS/NZS 4777.1.
- Warning labels on the inverter are as follows.

| | | | |
|---|--|---|--|
|  | DANGER High voltage hazard. Disconnect all incoming power and turn off the product before working on it. |  | Delayed discharge. Wait 5 minutes after power off until the components are completely discharged. |
|  | Read through the user manual before working on this device. |  | Potential risks exist. Wear proper PPE before any operations. |
|  | High-temperature hazard. Do not touch the product under operation to avoid being burnt. |  | Grounding point. |
|  | CE Mark |  | Do not dispose of the inverter as household waste. Discard the product in compliance with local laws and regulations, or send it back to the manufacturer. |

2.5 Personal Requirements

NOTICE

- Personnel who install or maintain the equipment must be strictly trained, learn about safety precautions and correct operations.
- Only qualified professionals or trained personnel are allowed to install, operate, maintain, and replace the equipment or parts.

2.6 EU Declaration of Conformity

GoodWe Technologies Co., Ltd. hereby declares that the inverter with wireless communication modules sold in the European market meets the requirements of the following directives:

- Radio Equipment Directive 2014/53/EU (RED)
- Restrictions of Hazardous Substances Directive 2011/65/EU and (EU) 2015/863 (RoHS)
- Waste Electrical and Electronic Equipment 2012/19/EU
- Registration, Evaluation, Authorization and Restriction of Chemicals (EC) No 1907/2006 (REACH)

GoodWe Technologies Co., Ltd. hereby declares that the inverter without wireless communication modules sold in the European market meets the requirements of the following directives:


- Electromagnetic compatibility Directive 2014/30/EU (EMC)
- Electrical Apparatus Low Voltage Directive 2014/35/EU (LVD)
- Restrictions of Hazardous Substances Directive 2011/65/EU and (EU) 2015/863 (RoHS)
- Waste Electrical and Electronic Equipment 2012/19/EU
- Registration, Evaluation, Authorization and Restriction of Chemicals (EC) No 1907/2006 (REACH)

You can download the EU Declaration of Conformity on <https://en.goodwe.com>.



3 Product Introduction

3.1 Application Scenarios

The MS inverter is a single-phase PV string grid-tied inverter. The inverter converts the DC power generated by the PV module into AC power and feeds it into the utility grid. The intended use of the inverter is as follows:




3.2 Circuit Diagram



3.3 Supported Grid Types

For the grid type with neutral wire, the N to ground voltage must be less than 10V.



3.4 Features

AFCI Detection Function (optional)

The AFCI detection function is used to detect the arc status on the DC side of the inverter. When arcing occurs, it is prohibited to connect the inverter to the grid.

Reasons for generating electric arcs:

- The connector in the photovoltaic system is damaged.
- Cable connection error or damage.
- Aging of connectors and cables.


Arc detection method:

- The inverter has integrated AFCI function and met the IEC 63027 standard.
- When the inverter detects an arc, the fault type can be viewed through the inverter's display screen or App.

| Model | Tag | Description |
|---------------|------------------|--|
| GW5000-MS-30 | F-I-AFPE-1-1/2-2 | F: Full coverage I: Integrated AFPE: Detection and interruption capability provided 1: 1 monitored string per input port 1/2: 1 or 2 input ports per channel 2: 2 monitored channel |
| GW6000-MS-30 | | |
| GW7000-MS-30 | | |
| GW8500-MS-30 | | |
| GW9900-MS-30 | | |
| GW10K-MS-30 | | |
| GW7000-MS-C30 | F-I-AFPE-1-2-1 | F: Full coverage I: Integrated AFPE: Detection and interruption capability provided 1: 1 monitored string per input port 2: 2 input ports per channel 1: 1 monitored channel |
| GW8000-MS-C30 | | |

3.5 Appearance

3.5.1 Parts
















| No. | Parts | Description |
|-----|--|--|
| 1 | DC Switch Lock | Only for Australia. Turn the DC switch to OFF and lock it to avoid electric shock when you have to work on the inverter. |
| 2 | DC Switch | Start or stop DC input. |
| 3 | PV Input Terminal | Used to connect the PV module DC input cables. |
| 4 | COM Port for communication module, USB-RS485 cable or USB. | <ul style="list-style-type: none"> Connect a communication module like Bluetooth, WiFi/LAN, WiFi, GPRS, 4G, etc. The module type may differ depending on actual needs. Connect the USB-RS485 cable in Brazil. Update the software version of the inverter using a USB flash driver. |
| 5 | COM Port for RS485, remote shutdown, meter, or CT. | Used to connect the RS485, meter, CT, or remote shutdown communication cable. |
| 6 | COM Port for DRED or dry contact. | Reserved port. Used to connect the DRED cable or dry contact cable. |









| No. | Parts | Description |
|-----|-------------------|--|
| 7 | AC Terminal | Used to connect the AC output cable, which connects the inverter and the utility grid. |
| 8 | Grounding Point | Used to connect the PE cable. |
| 9 | Indicator | Indicates working state of the inverter. |
| 10 | LCD (optional) | Optional. Used to check the parameters of the inverter. |
| 11 | Button (optional) | Optional. Used to select menus displayed on the screen. |
| 12 | Mounting Plate | Used to install the inverter. |
| 13 | Heat sink | Used to cool the inverter. |









3.5.2 Indicators

With LCD

| Indicator | Status | Description |
|--|---|---|
|  Power |  | ON = Wi-Fi is connected/active |
| |  | Blink 1 = Wi-Fi system is resetting |
| |  | Blink 2 = Not connected to the router |
| |  | Blink 4 = Wi-Fi server problem |
| |  | Blink = RS485 is connected |
| |  | OFF = Wi-Fi is not active |
|  Operating |  | ON = The inverter is feeding power |
| |  | OFF = The inverter is not feeding power at the moment |
|  Faulty |  | ON = A fault has occurred |
| |  | OFF = No fault |









Without LCD

| Indicator | Status | Description |
|--|---|--|
|  Power |  | ON = Equipment Power On |
| |  | OFF = Equipment Power Off |
|  Operating |  | ON = The Inverter Is Feeding Power |
| |  | OFF = The inverter is not feeding power |
| |  | Single slow flash = Self check before connecting to the grid |
| |  | Single flash = Connecting to the grid |

| Indicator | Status | Description |
|-----------|---|---|
| SEMS |  | ON = Wireless is connected/active |
| |  | Blink 1 = Wireless system is resetting |
| |  | Blink 2 = Wireless router not connected |
| |  | Blink 4 = Wireless server problem |
| |  | Blink = RS485 is connected |
| |  | OFF = Wireless is not active |
| Faulty |  | ON = A fault has occurred |
| |  | OFF = No fault |

3.5.3 Nameplate

The nameplate is for reference only.

| <h1>GOODWE</h1> | |
|---|--------------------|
| Product: Grid-Tied PV Inverter Model : *****_****_** | |
| PV Input | UDCmax: **** Vd.c. |
| | UMPP: **.* Vd.c. |
| | IDC,max: ** Ad.c. |
| | ISC PV: ** Ad.c. |
| Output | UAC,r: *** Va.c. |
| | fAC,r: ** Hz |
| | PAC,r: ** kW |
| | IAC,max: ** Aa.c. |
| | SR: ** kVA |
| | Smax: ** kVA |
| P.F.: ~, **cap...ind Toperating: -~** °C Non-isolated, IP**, protective Class I, OVC DCII/ACIII | |
| <div>     </div> <div>     </div> | |
| S/N: | |
| ***** Co., Ltd. E-mail: *****@****.com ***** | |

4 Check and Storage

4.1 Check Before Receiving


Check the following items before receiving the product.

1. Check the outer packing box for damage, such as holes, cracks, deformation, and other signs of equipment damage. Do not unpack the package and contact the supplier as soon as possible if any damage is found.
2. Check the inverter model. If the inverter model is not what you requested, do not unpack the product and contact the supplier.
3. Check the deliverables for correct model, complete contents, and intact appearance. Contact the supplier as soon as possible if any damage is found.

Notice

- The type and number of the 2PIN terminal and the 6PIN terminal are decided by the selected communication method.
- Communication module types: WiFi/LAN kit-20, Wi-Fi/LAN kit, Wi-Fi kit, LAN kit, GPRS, Bluetooth, 4G kit, etc. The actual module delivered depends on the communication method of the selected inverter.
- USB-RS485 cable is optional. Only for Brazil.
- The quantity of Ezlink is decided by the selected communication method. Confirm the number according to the communication configuration.

4.2 Deliverables



4.3 Storage

If the equipment is not to be installed or used immediately, please ensure that the storage environment meets the following requirements:





1. Do not unpack the outer package or throw the desiccant away.
2. Store the equipment in a clean place. Make sure the temperature and humidity are appropriate and no condensation.
3. The height and direction of the stacking inverters should follow the instructions on the packing box.
4. The inverters must be stacked with caution to prevent them from falling.
5. If the inverter has been long term stored, it should be checked by professionals before being put into use.


5 Installation

5.1 Installation Requirements

Installation Environment Requirements

1. Do not install the equipment in a place near flammable, explosive, or corrosive materials.
2. Install the equipment on a surface that is solid enough to bear the inverter weight.
3. Install the equipment in a well-ventilated place to ensure good dissipation. Also, the installation space should be large enough for operations.
4. The equipment with a high ingress protection rating can be installed indoors or outdoors. The temperature and humidity at the installation site should be within the appropriate range.
5. Install the equipment in a sheltered place to avoid direct sunlight, rain, and snow. Build a sunshade if it is needed.
6. Install the equipment in a well-ventilated place to ensure good dissipation. Also, the installation space should be large enough for operations.
7. Do not install the equipment in a place that is easy to touch, especially within children's reach. High temperature exists when the equipment is working. Do not touch the surface to avoid burning.
8. Install the equipment at a height that is convenient for operation and maintenance, electrical connections, and checking indicators and labels.
9. The altitude to install the inverter shall be lower than the maximum working altitude 4000m.
10. The inverter is easy to be corroded when installed in salt areas. Please consult the inverter manufacturer before installing it outdoors in salt areas. A salt area refers to the region within 1000m offshore or affected by the sea breeze. The area prone to the sea breeze varies depending on weather conditions (e.g. typhoon, monsoon) or terrain (such as dams and hills).
11. Install the inverter away from high magnetic field to avoid electromagnetic interference. If there is any radio or wireless communication equipment below 30MHz near the inverter, you have to:
 - Install the inverter at least 30m far away from the wireless equipment.
 - Add a low pass EMI filter or a multi winding ferrite core to the DC input cable or AC output cable of the inverter.






Mounting Support Requirements

- The mounting support shall be nonflammable and fireproof.
- Make sure that the support surface is solid enough to bear the product weight load.
- Do not install the product on the support with poor sound insulation to avoid the noise generated by the working product, which may annoy the residents nearby.

Installation Angle Requirements

- Install the inverter vertically or at a maximum back tilt of 15 degrees.
- Do not install the inverter upside down, forward tilt, back forward tilt, or horizontally.



Installation Tool Requirements

The following tools are recommended when installing the equipment. Use other auxiliary tools on site if necessary.

| | | | | |
|---|---|---|---|---|
|  |  |  |  |  |
| Goggles | Safety shoes | Safety gloves | Dust mask | DC terminal crimping tool |
|  |  |  |  |  |
| Diagonal pliers | Wire stripper | Hammer drill | Heat gun | DC wiring wrench |
|  |  |  |  |  |
| Marker | Level | Heat shrink tube | Rubber hammer | Vacuum cleaner |
|  |  |  | | |
| Multimeter | Cable tie | Torque wrench | | |

5.2 Inverter Installation

5.2.1 Moving the Inverter

CAUTION

- Operations such as transportation, turnover, installation and so on must meet the requirements of the laws and regulations of the country or region where it is located.
- Move the inverter to the site before installation. Follow the instructions below to avoid personal injury or equipment damage.
 1. Consider the weight of the equipment before moving it. Assign enough personnel to move the equipment to avoid personal injury.
 2. Wear safety gloves to avoid personal injury.
 3. Keep balance to avoid falling down when moving the equipment.

NOTICE

- Avoid the water pipes and cables buried in the wall when drilling holes.
- Wear goggles and a dust mask to prevent the dust from being inhaled or contacting eyes when drilling holes.
- The DC switch lock shall be prepared by customers with hole diameter: $\phi 8\text{mm}$. Select appropriate size. Otherwise it is unable to finish the installation.
- The anti-theft lock shall be prepared by customers with hole diameter: $\phi 10\text{mm}$. Select appropriate size. Otherwise it is unable to finish the installation.
- Make sure the inverter is firmly installed in case of falling down.

Step 1 Put the mounting plate on the wall or the support horizontally and mark positions for drilling holes.


Step 2 Drill holes to a depth of 80mm using the hammer drill. The diameter of the drill bit should be 8mm.



Step 3 Secure the mounting plate using the expansion bolts.

Step 4 (Only for Australia.) Install the DC switch lock.

Step 5 Install the inverter on the mounting plate.

Type-1





Type-2

Step 1 Put the mounting plate on the wall or the support horizontally and mark positions for drilling holes.

Step 2 Drill holes to a depth of 80mm using the hammer drill. The diameter of the drill bit should be 8mm.




Step 3 Secure the mounting plate using the expansion bolts.


Step 4 (Only for Australia.) Install the DC switch lock.

Step 5 Install the inverter on the mounting plate.

Step 6: Tighten the nuts to secure the mounting plate and the inverter.

Step 7: Install the anti-theft lock.





6 Electrical Connection

6.1 Safety Precaution

! DANGER


- Disconnect the DC switch and the AC output switch of the inverter to power off the inverter before any electrical connections. Do not work with power on. Otherwise, an electric shock may occur.
- Perform electrical connections in compliance with local laws and regulations. Including operations, cables, and component specifications.
- If the cable bears too much tension, the connection may be poor. Reserve a certain length of the cable before connecting it to the inverter cable port.

NOTICE

- Wear personal protective equipment like safety shoes, safety gloves, and insulating gloves during electrical connections.
- All electrical connections should be performed by qualified professionals.
- Cable colors in this document are for reference only. The cable specifications shall meet local laws and regulations.

WARNING

- Connect the DC cables using the delivered PV connectors. The manufacturer shall not be liable for the damage if other connectors are used.
- The PV strings cannot be grounded. Ensure the minimum isolation resistance of the PV string to the ground meets the minimum isolation resistance requirements before connecting the PV string to the inverter.
- The DC input cable is prepared by the customer. Recommended specifications:
 - Type: the outdoor photovoltaic cable that meets the maximum input voltage of the inverter.
 - Conductor cross-sectional area: 2.5~4mm² (Devalan) or 4~6mm² (MC4).

**NOTICE**

Seal the PV input terminals using waterproof covers when they are not to be used. Otherwise, the ingress protection rating will be influenced.

Connecting the DC Input Cable


Step 1 Prepare DC cables.




Step 2 Crimp the crimp contacts.

Step 3 Disassemble the PV connectors.




Step 4 Make the DC cable and detect the DC input voltage.


Step 5 Plug the PV connectors into the PV terminals.

Devalan PV connector




Stäubli MC4 PV connector





Disconnect PV connector, must use tool mentioned in picture below



6.4 Connecting the AC Output Cable

⚠ WARNING

- Do not connect loads between the inverter and the AC switch directly connected to the inverter.
- The Residual Current Monitoring Unit (RCMU) is integrated into the inverter. The inverter will disconnect the utility grid rapidly once it detects any leak current over the permissible range.

An AC circuit breaker shall be installed on the AC side to make sure that the inverter can safely disconnect the grid when an exception happens. Select the appropriate AC circuit breaker in compliance with local laws and regulations. Recommended AC circuit breakers:

| Inverter model | AC circuit breaker |
|----------------|--------------------|
| GW5000-MS-30 | 32A |
| GW6000-MS-30 | 40A |
| GW7000-MS-30 | 50A |
| GW8500-MS-30 | 63A |
| GW9900-MS-30 | 63A |
| GW10K-MS-30 | 63A |
| GW7000-MS-C30 | 50A |
| GW8000-MS-C30 | 50A |

A type A RCD(Residual Current Device) shall be added to protect the equipment when the DC component of the leakage current exceeds limits. Recommended RCD specifications:

| Model | RCD specifications |
|---------------|--------------------|
| GW5000-MS-30 | 300mA |
| GW6000-MS-30 | |
| GW7000-MS-30 | |
| GW8500-MS-30 | |
| GW9900-MS-30 | |
| GW10K-MS-30 | |
| GW7000-MS-C30 | |
| GW8000-MS-C30 | |

NOTICE

- Install one AC circuit breaker for each inverter. Multiple inverters cannot share one AC circuit breaker.
- Seal the AC output terminals with waterproof covers when they are not to be used. Otherwise, the ingress protection rating will be influenced.



WARNING



- Pay attention to the silkscreens L, N, PE on the AC terminal. Connect the AC cables to the corresponding terminals. The inverter may be damaged if the cables are connected inappropriately.
- Make sure that the whole cable cores are inserted into the AC terminal holes. No part of the cable core can be exposed.
- Make sure that the cables are connected securely. Otherwise, the terminal may be too hot to damage the inverter when the inverter is working.

Step 1 Make the AC output cable.





Step 2 Disassemble the AC connector.

Step 3 Insert the AC output cable into the AC connector.


Step 4 Plug the AC connector into the inverter.



AC-1



Disconnect AC connector




6.5 Communication

6.5.1 Communication Network Introduction

Power Limit Network

The PV station generates power for self-consumption, but the electric equipment cannot consume all the generated power. The inverter can monitor the on-grid electric data in real-time and adjust the output power via a smart meter to avoid the residual current feeding back to the utility grid.

GM1000




Both the current sampling accuracy error margin of CT and the output voltage sampling accuracy error margin of the inverter are $\pm 1\%$, so the output power sampling accuracy error margin of the inverter is $\pm 2\%$.




Load Monitoring Network

HK1000




6.5.2 Communication Port Introduction



| Communication Type | Terminal | Definition | Function |
|---|----------|--|---|
| RS485 | RS485 | 1: RS485 - 2: RS485 + | It supports connecting to the upper computer for commissioning. Please contact the after-sales service for detail information. |
| Remote Shutdown (For Europe only) or Rapid ShutDown (For North America only) or Emergency Power Off(For India only) | RSD | 3: Remote Shutdown/EPO - 4: Remote Shutdown/EPO + | The port is reserved in compliance with grid regulations in Europe. Related devices should be prepared by customers. |
| Dry contact | I/O | 5: I/O3- 6: I/O3+ 7: I/O2- 8: I/O2+ 9: I/O1- 10: I/O1+ | Reserved. |
| Meter | Meter | 11: Meter- 12: Meter+ | Realize the anti-backfeed function by connecting the meter and the CT. Contact the manufacturer to purchase the devices if you need them. |
| CT | CT | 13: CT- 14: CT+ | |
| DRED | DRED | 15: COM/DRM0 16: REFGEN 17: DRM4/8 18: DRM3/7 19: DRM2/6 20: DRM1/5 | The inverter meets the DRED grid scheduling requirement in Australia and New Zealand. Functions for DRM 1-4 ports are reserved. Devices for DRM shall be prepared by the clients. |

6.5.3 DRM Description



Wiring Diagram of DRM



The inverter supports DRM0 and DRM 5-8 modes. Below are the requirements:

| Mode | Inverter Port | Requirement | Note |
|------|---------------|--|--|
| DRM0 | COM/DRM0 | Turn on S0 and the inverter shuts down. Turn off S0 and the inverter is back to on-grid. | - |
| DRM5 | DRM1/5 | Turn on S5 and the inverter does not output Active Power. | When two or more than 2 DRMs are working simultaneously, select any two of them can satisfy the strictest requirement. |
| DRM6 | DRM2/6 | Turn on S6 and the inverter outputs Active Power no more than 50% of its rated power. | |
| DRM7 | DRM3/7 | Turn on S7 and the inverter outputs Active Power no more than 75% of its rated power. In the meantime, the inverter consumes the maximum Reactive Power. | |
| DRM8 | DRM4/8 | Turn on S8 and the inverter is back to Active Power output. | |




The wiring method of communication terminals is as follows:




6.5.4 Connecting the Communication Cable (optional)

Notice

- Make sure that the communication device is connected to the right terminal. Route the communication cable far away from any interference source or power cable to prevent the signal from being influenced.
- Connect the RS485 cable, remote shutdown cable, meter cable, and CT cable using a 2PIN communication terminal.
- Connect the dry contact cable and DRED cable using a 6PIN communication terminal.
- Remove the short circuit wire and keep it properly when enabling the DRED function.






6.5.5 Installing the Communication Module (optional)

Plug a communication module into the inverter to establish a connection between the inverter and the smartphone or web pages. The communication module can be a Bluetooth module, WiFi module, LAN module, GPRS module, or 4G module. Set inverter parameters, check running information and fault information, and observe system status in time via the smartphone or web pages.

WiFi kit, LAN kit, 4G kit, GPRS, Bluetooth Kit, Wi-Fi/LAN Kit, WiFi/LAN Kit-20 module: optional.




Notice

Refer to the delivered communication module user manual to get more introduction to the module. For more detailed information, visit <https://en.goodwe.com>.

6.5.6 Connecting the USB-RS485 Cable(Optional)

USB-RS485 cable: Only for Brazil.



7 Equipment Commissioning

7.1 Check Before Power ON


| No. | Check Item |
|-----|---|
| 1 | The product is firmly installed at a clean place that is well-ventilated and easy to operate. |
| 2 | The PE, DC input, AC output, and communication cables are connected correctly and securely. |
| 3 | Cable ties are intact, routed properly and evenly. |
| 4 | Unused ports and terminals are sealed. |
| 5 | The voltage and frequency at the connection point meet the inverter grid connection requirements. |

7.2 Power On

Step 1 Turn on the AC switch between the inverter and the utility grid.

Step 2 Turn on the DC switch of the inverter.














Step 3 (optional) Turn on the DC switch between the inverter and the PV string.





















8 System Commissioning

8.1 Indicators and Buttons

With LCD

| Indicator | Status | Description |
|--|---|---|
|  Power |  | ON = Wi-Fi is connected/active |
| |  | Blink 1 = Wi-Fi system is resetting |
| |  | Blink 2 = Not connected to the router |
| |  | Blink 4 = Wi-Fi server problem |
| |  | Blink = RS485 is connected |
| |  | OFF = Wi-Fi is not active |
|  Operating |  | ON = The inverter is feeding power |
| |  | OFF = The inverter is not feeding power at the moment |
|  Faulty |  | ON = A fault has occurred |
| |  | OFF = No fault |

Without LCD

| Indicator | Status | Description |
|--|---|--|
|  Power |  | ON = Equipment Power On |
| |  | OFF = Equipment Power Off |
|  Operating |  | ON = The Inverter Is Feeding Power |
| |  | OFF = The inverter is not feeding power |
| |  | Single slow flash = Self check before connecting to the grid |
| |  | Single flash = Connecting to the grid |
|  SEMS |  | ON = Wireless is connected/active |
| |  | Blink 1 = Wireless system is resetting |
| |  | Blink 2 = Wireless router not connected |
| |  | Blink 4 = Wireless server problem |
| |  | Blink = RS485 is connected |
| |  | OFF = Wireless is not active |
|  Faulty |  | ON = A fault has occurred |
| |  | OFF = No fault |

8.2 Setting Inverter Parameters via LCD


NOTICE

- Inverter firmware version shown in this document is V1.00.00. Communication version: V1.00. The screenshots are for reference only. The actual interface may differ.
- The name, range, and default value of the parameters are subject to change or adjustment. The actual display prevails.
- To prevent the generating capacity from being influenced by wrong parameters, the power parameters should be set by professionals.

LCD Button Description

- Stop pressing the button for a period on any page, the LCD will get dark and go back to the initial page.
- Short press the button to switch menu or adjust parameter values.
- Long press the button to enter the submenu. After adjusting the parameter values, long press to set it.


Examples:



For Australia:


User need type the password to enter the sub-menu for parameter setting.

For the Australian Market, to comply with AS/NZS 4777.2:2020 please select grid/safety code from Australia A, Australia B or Australia C. please contact your local grid operator for which setting to apply



8.2.1 LCD Menu Introduction

This part describes the menu structure, allowing you to view inverter information and set parameters more conveniently.



8.2.2 Inverter Parameter Introduction

| Parameters | Description |
|------------------------|--|
| Normal | Home page. Indicates the real-time power of the inverter. |
| 2022-02-14 09:01:10 | Check the time of the country/region. |
| VPv1 | Check the DC input voltage of the inverter. |
| IPv1 | Check the DC input current of the inverter. |
| Vac | Check the voltage of the utility grid. |
| Iac | Check the AC output current of the inverter. |
| Fac | Check the frequency of the utility grid. |
| E-Today | Check the generated power of the system for that day. |
| E-Total | Check the total generated power of the system. |
| Serial Number | Check the serial number of the inverter. |
| GW5000-MS-30 RSSI | Check the signal strength of the communication module. |
| Firmware M/S | Check the firmware version. |
| Comm Version | Check the ARM software version. |
| Set Safety | Set the safety country/region in compliance with the local grid standards and application scenario of the inverter. |
| Set Date | Set time according to the actual time in the country/region where the inverter is located. |
| Set Time | |
| Set Password | The password can be changed. Keep the changed password in mind after changing it. Contact the after-sales service if you forget the password. |
| W/L Reset | Power off and restart the communication module. |
| W/L Reload | Restore the factory settings of the communication module. Reconfigure the communication module network parameters after restoring the factory settings, |
| PF Adjust | Set the power factor of the inverter according to the actual situation. |
| SetModbusAddr | Set the actual Modbus address. |
| Set ISO | Indicates the PV-PE insulation resistance threshold value. When the detected value is under the set value, the ISO fault occurs. |

| Parameters | Description |
|----------------|---|
| LVRT | With LVRT on, the inverter will stay connected with the utility grid after a short-term utility grid low voltage exception occurs. |
| HVRT | With HVRT on, the inverter will stay connected with the utility grid after a short-term utility grid high voltage exception occurs. |
| Power Limit | Set the power feed back into the utility grid according to the actual situation. |
| SetPowerLimit | |
| Pv1ShadowMPPT | Enable the shadow scan function if the PV panels are shadowed. |
| PV2ShadowMPPT | |
| PV3ShadowMPPT | |
| PvTimeInterval | Set the scan time according to the actual needs. |
| SetSunspec | Set the Sunspeg based on the actual communication method. |
| ARC Enable | ARC is optional and off by default. Enable or disable ARC accordingly. |
| ARC SelfCheck | Check whether ARC can work normally. |
| ARC FaultClear | Clear ARC alarm records. |
| ViewFaults | Check historical error message records of the inverter. |
| ClearFaults | Clear historical error message records of the inverter. |

8.3 Upgrading the Firmware

8.3.1 Upgrading the Firmware Via USB-RS485 Cable

Contact After Sale Service if the inverter shall be connected with USB-485 cable to upgrade the software version.

8.3.2 Upgrading the Firmware Via USB Flash Disk

- Step 1** Contact the after-sales service to obtain the upgrade package.
- Step 2** Save the upgrade package in the USB flash drive.
- Step 3** Insert the USB flash drive into the USB port, and upgrade the software version of the inverter following the prompts.

8.4 Setting Inverter Parameters via SolarGo App

SolarGo app is a mobile application that communicates with the inverter via Bluetooth module, WIFI module or GPRS module. Commonly used functions are as follows:

1. Check the operating data, software version, alarms, etc.
2. Set grid parameters, communication parameters, etc.
3. Equipment maintenance.

For more details, refer to the SolarGo APP User Manual. Scan the QR code or visit https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW_SolarGo_User%20Manual-EN.pdf to get the user manual.



SolarGo App



SolarGo App User Manual

8.5 Monitoring via SEMS Portal

SEMS Portal is an monitoring platform used to manage organizations/users, add plants, and monitor plant status.

For more details, refer to the SEMS Portal User Manual. Scan the QR code or visit https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW_SEMS%20Portal-User%20Manual-EN.pdf to get the user manual.



SEMS Portal



SEMS Portal
User Manual

Maintenance

9.1 Power Off the Inverter

! DANGER

- Power off the inverter before operations and maintenance. Otherwise, the inverter may be damaged or electric shocks may occur.
- Delayed discharge. Wait until the components are discharged after power off.

- Step 1** (optional) Send shutdown command to the inverter.
- Step 2** Turn off the AC switch between the inverter and the utility grid.
- Step 3** Turn off the DC switch of the inverter.

9.2 Removing the Inverter

! WARNING

- Make sure that the inverter is powered off.
- Wear proper PPE before any operations.

- Step 1** Disconnect all the cables, including DC cables, AC cables, communication cables, the communication module, and PE cables.
- Step 2** Grab the handles or hoist the inverter to remove the inverter from the mounting plate.
- Step 3** Remove the mounting plate.
- Step 4** Store the inverter properly. If the inverter needs to be used later, ensure that the storage conditions meet the requirements.

9.3 Disposing of the Inverter

If the inverter cannot work anymore, dispose of it according to the local disposal requirements for electrical equipment waste. The inverter cannot be disposed of together with household waste.

9.4 Troubleshooting

- Perform troubleshooting according to the following methods. Contact the after-sales service if these methods do not work.
- Collect the information below before contacting the after-sales service, so that the problems can be solved quickly.
1. Inverter information like serial number, software version, installation date, fault time, fault frequency, etc.
 2. Installation environment, including weather conditions, whether the PV modules are sheltered or shadowed, etc. It is recommended to provide some photos and videos to assist in analyzing the problem.
 3. Utility grid situation.

| No. | Fault | Cause | Solutions |
|-----|------------------------|--|--|
| 1 | Utility Loss | 1. Utility grid power fails. 2. The AC cable is disconnected, or the AC breaker is off. | 1. The alarm is automatically cleared after the grid power supply is restored. 2. Check whether the AC cable is connected and the AC breaker is on. |
| 2 | Grid Overvoltage | The grid voltage exceeds the permissible range, or the duration of high voltage exceeds the requirement of HVRT. | 1. If the problem occurs occasionally, the utility grid may be abnormal temporarily. The inverter will recover automatically after detecting that the utility grid is normal. 2. If the problem occurs frequently, check whether the grid voltage is within the permissible range. <ul style="list-style-type: none"> • Contact the local power company if the grid voltage exceeds the permissible range. • Modify the overvoltage protection threshold, HVRT or disable the overvoltage protection function after obtaining the consent of the local power company if the grid frequency is within the permissible range. 3. Check whether the AC breaker and the output cables are connected securely and correctly if the problem persists. |
| 3 | Grid Rapid Overvoltage | The grid voltage is abnormal or ultra-high. | 1. If the problem occurs occasionally, the utility grid may be abnormal temporarily. The inverter will recover automatically after detecting that the utility grid is normal. 2. If the problem occurs frequently, check whether the grid voltage is within the allowed range. <ul style="list-style-type: none"> • Contact the local power company if the grid voltage exceeds the permissible range. • Modify the grid overvoltage rapid protection threshold after obtaining the consent of the local power company if the grid voltage is within the permissible range. |

| No. | Fault | Cause | Solutions |
|-----|------------------------|---|--|
| 4 | Grid Undervoltage | The grid voltage is lower than the permissible range, or the duration of low voltage exceeds the requirement of LVRT. | <ol style="list-style-type: none"> 1. If the problem occurs occasionally, the utility grid may be abnormal temporarily. The inverter will recover automatically after detecting that the utility grid is normal. 2. If the problem occurs frequently, check whether the grid voltage is within the permissible range. <ul style="list-style-type: none"> • Contact the local power company if the grid voltage exceeds the permissible range. • Modify the undervoltage protection threshold, LVRT or disable the undervoltage protection function after obtaining the consent of the local power company if the grid frequency is within the permissible range. 3. Check whether the AC breaker and the output cables are connected securely and correctly if the problem persists. |
| 5 | Grid 10min Overvoltage | The moving average of grid voltage in 10min exceeds the range of safety requirements. | <ol style="list-style-type: none"> 1. If the problem occurs occasionally, the utility grid may be abnormal temporarily. The inverter will recover automatically after detecting that the utility grid is normal. 2. If the problem occurs frequently, check whether the grid voltage is within the permissible range. <ul style="list-style-type: none"> • Contact the local power company if the grid voltage exceeds the permissible range. • Modify the 10min overvoltage protection threshold with the consent of the local power company if the grid voltage is within the permissible range. |

| No. | Fault | Cause | Solutions |
|-----|----------------------------|---|---|
| 6 | Grid Overfrequency | Utility grid exception. The actual grid frequency exceeds the requirement of the local grid standard. | <ol style="list-style-type: none"> 1. If the problem occurs occasionally, the utility grid may be abnormal temporarily. The inverter will recover automatically after detecting that the utility grid is normal. 2. If the problem occurs frequently, check whether the grid frequency is within the permissible range. <ul style="list-style-type: none"> • Contact the local power company if the grid frequency exceeds the permissible range. • Modify the overfrequency protection threshold or disable the overfrequency protection function after obtaining the consent of the local power company if the grid frequency is within the permissible range. |
| 7 | Grid Underfrequency | Utility grid exception. The actual grid frequency is lower than the requirement of the local grid standard. | <ol style="list-style-type: none"> 1. If the problem occurs occasionally, the utility grid may be abnormal temporarily. The inverter will recover automatically after detecting that the utility grid is normal. 2. If the problem occurs frequently, check whether the grid frequency is within the permissible range. <ul style="list-style-type: none"> • Contact the local power company if the grid frequency exceeds the permissible range. • Modify the underfrequency protection threshold or disable the underfrequency protection function after obtaining the consent of the local power company if the grid frequency is within the permissible range. |
| 8 | Grid Frequency Instability | Utility grid exception. The actual grid frequency change rate does not meet the requirement of the local grid standard. | <ol style="list-style-type: none"> 1. If the problem occurs occasionally, the utility grid may be abnormal temporarily. The inverter will recover automatically after detecting that the utility grid is normal. 2. If the problem occurs frequently, check whether the grid frequency is within the permissible range. <ul style="list-style-type: none"> • Contact the local power company if the grid frequency exceeds the permissible range. • Contact the dealer or the after-sales service if the grid frequency is within the permissible range. |

| No. | Fault | Cause | Solutions |
|-----|---------------------------|--|---|
| 9 | Anti-islanding | The utility grid is disconnected. The utility grid is disconnected according to the safety regulations, but the grid voltage is maintained due to the loads. | <ol style="list-style-type: none"> 1. Check whether the utility grid is disconnected. 2. Contact the dealer or the after-sales service. |
| 10 | LVRT Undervoltage | Utility grid exception. The duration of the utility grid exception exceeds the set time of LVRT. | <ol style="list-style-type: none"> 1. If the problem occurs occasionally, the utility grid may be abnormal temporarily. The inverter will recover automatically after detecting that the utility grid is normal. 2. If the problem occurs frequently, check whether the grid frequency is within the permissible range. If not, contact the local power company. If yes, contact the dealer or the after-sales service. |
| 11 | HVRT Overvoltage | Utility grid exception. The duration of utility grid exception exceeds the set time of HVRT. | |
| 12 | Abnormal GFCI 30mA | The input insulation impedance becomes low when the inverter is working. | <ol style="list-style-type: none"> 1. If the problem occurs occasionally, it may be caused by a cable exception. The inverter will recover automatically after the problem is solved. 2. Check whether the impedance between the PV string and PE is too low if the problem occurs frequently or persists. |
| 13 | Abnormal GFCI 60mA | | |
| 14 | Abnormal GFCI 150mA | | |
| 15 | Abnormal GFCI | | |
| 16 | Large DC of AC current L1 | The DC component of the output current exceeds the safety range or default range. | <ol style="list-style-type: none"> 1. If the problem is caused by an external fault like a utility grid exception or frequency exception, the inverter will recover automatically after solving the problem. 2. If the problem occurs frequently and the PV station cannot work properly, contact the dealer or the after-sales service. |
| 17 | Large DC of AC current L2 | | |

| No. | Fault | Cause | Solutions |
|-----|--|--|--|
| 18 | Low Insulation Res.(Earth fault alarm) | <ol style="list-style-type: none"> 1. The PV string is short-circuited to PE. 2. The PV system is in a moist environment and the cable is not well insulated to the ground. | <ol style="list-style-type: none"> 1. Check whether the resistance of the PV string to PE exceeds 50kΩ. If no, check the short circuit point. 2. Check whether the PE cable is connected correctly. 3. If the resistance is lower on rainy days, please reset the ISO. <p>Inverters for the Australian and New Zealand markets can also be alerted in the following ways in the event of insulation impedance failure:</p> <ol style="list-style-type: none"> 1. The inverter is equipped with the buzzer: the buzzer sounds continuously for 1 minute in case of failure; If the fault is not resolved, the buzzer sounds every 30 minutes. 2. Add the inverter to the monitoring platform, and set the alarm reminder, the alarm information can be sent to the customer by emails. |
| 19 | Abnormal Ground | <ol style="list-style-type: none"> 1. The PE cable of the inverter is not connected well. 2. The L cable and N cable are connected reversely when output of the PV string is grounded. | <ol style="list-style-type: none"> 1. Check whether the PE cable of the inverter is connected properly. 2. Check whether the L cable and N cable are connected reversely if output of the PV string is grounded. |
| 20 | Anti Reverse power Failure | Abnormal fluctuation of load | <ol style="list-style-type: none"> 1. If the exception is caused by an external fault, the inverter will recover automatically after solving the problem. 2. If the problem occurs frequently and the PV station cannot work properly, contact the dealer or the after-sales service. |

| No. | Fault | Cause | Solutions |
|-----|-------------------------|--|--|
| 21 | Internal Comm Loss | <ol style="list-style-type: none"> 1. Frame format error 2. Parity checking error 3. Can bus offline 4. Hardware CRC error 5. Send (receive) control bit is receive (send). 6. Transmit to the unit that is not allowed. | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists. |
| 22 | AC HCT Check abnormal | The sampling of the AC HCT is abnormal. | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists. |
| 23 | GFCI HCT Check abnormal | The sampling of the GFCI HCT is abnormal. | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists. |
| 24 | Relay Check abnormal | <ol style="list-style-type: none"> 1. The relay is abnormal or short-circuited. 2. The control circuit is abnormal. 3. The AC cable connection is abnormal, like a virtual connection or short circuit. | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists. |
| 25 | Internal Fan abnormal | <ol style="list-style-type: none"> 1. The fan power supply is abnormal. 2. Mechanical exception. 3. The fan is aging and damaged. | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists. |
| 26 | Flash Fault | The internal Flash storage is abnormal. | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists. |

| No. | Fault | Cause | Solutions |
|-----|------------------------------------|--|--|
| 27 | DC Arc Fault | <ol style="list-style-type: none"> 1. The DC terminal is not firmly connected. 2. The DC cable is broken. | Read the Quick Installation Guide and check whether the cables are connected properly. |
| 28 | AFCI Self-test Fault | AFCI detection is abnormal. | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists. |
| 29 | Cavity Overtemperature | <ol style="list-style-type: none"> 1. The inverter is installed in a place with poor ventilation. 2. The ambient temperature exceeds 60°C. 3. A fault occurs in the internal fan of the inverter. | <ol style="list-style-type: none"> 1. Check the ventilation and the ambient temperature at the installation point. 2. If the ventilation is poor or the ambient temperature is too high, improve the ventilation and heat dissipation. 3. Contact the dealer or after-sales service if both the ventilation and the ambient temperature are normal. |
| 30 | BUS Overvoltage | <ol style="list-style-type: none"> 1. The PV voltage is too high. 2. The sampling of the inverter BUS voltage is abnormal. | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists. |
| 31 | PV Input Overvoltage | The PV array configuration is not correct. Too many PV panels are connected in series in the PV string. | Check the serial connection of the PV array. Make sure that the open circuit voltage of the PV string is not higher than the maximum operating voltage of the inverter. |
| 32 | PV Continuous Hardware Overcurrent | <ol style="list-style-type: none"> 1. The PV configuration is not proper. 2. The hardware is damaged. | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists. |
| 33 | PV Continuous Software Overcurrent | <ol style="list-style-type: none"> 1. The PV configuration is not proper. 2. The hardware is damaged. | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists. |
| 34 | String1 PV String Reversed | The PV string is connected reversely. | Check whether the PV1 and PV2 strings are connected reversely. |
| 35 | String2 PV String Reversed | | |

9.5 Routine Maintenance

| Maintaining Item | Maintaining Method | Maintaining Period |
|-----------------------|---|--------------------|
| System Clean | Check the heat sink, air intake, and air outlet for foreign matter or dust. | Once 6-12 months |
| DC Switch | Turn the DC switch on and off ten consecutive times to make sure that it is working properly. | Once a year |
| Electrical Connection | Check whether the cables are securely connected. Check whether the cables are broken or whether there is any exposed copper core. | Once 6-12 months |
| Sealing | Check whether all the terminals and ports are properly sealed. Reseal the cable hole if it is not sealed or too big. | Once a year |

10 Technical Parameters

| Technical Parameters | GW5000-MS-30 | GW6000-MS-30 | GW7000-MS-30 | GW8500-MS-30 |
|--|---------------------------------------|--------------|--------------|--------------|
| Input | | | | |
| Max.Input Power (W) | 7,750 | 9,300 | 10,850 | 13,175 |
| Max.Input Voltage (V) | 600 | 600 | 600 | 600 |
| MPPT Operating Voltage Range (V) | 40~560 | 40~560 | 40~560 | 40~560 |
| MPPT Voltage Range at Nominal Power (V) | 85~500 | 102~500 | 120~500 | 145~500 |
| Start-up Voltage (V) | 50 | 50 | 50 | 50 |
| Nominal Input Voltage (V) | 360 | 360 | 360 | 360 |
| Max. Input Current per MPPT (A) | 20 | 20 | 20 | 20 |
| Max. Short Circuit Current per MPPT (A) | 25 | 25 | 25 | 25 |
| Max.Backfeed Current to The Array (A) | 0 | 0 | 0 | 0 |
| Number of MPP trackers | 3 | 3 | 3 | 3 |
| Number of Strings per MPPT | 1 | 1 | 1 | 1 |
| Output | | | | |
| Nominal Output Power (W) | 5,000 | 6,000 | 7,000 | 8,500 |
| Nominal Output Apparent Power (VA) | 5,000 | 6,000 | 7,000 | 8,500 |
| Max. AC Active Power (W) ^{*1*9} | 5,500 | 6,600 | 7,700 | 9,350 |
| Max. AC Apparent Power (VA) ^{*2*8} | 5,500 | 6,600 | 7,700 | 9,350 |
| Nominal Power at 40°C (W)(Only for Brazil) | NA | NA | 7,000 | 8,500 |
| Max Power at 40°C (including AC overload) (W)(Only for Brazil) | NA | NA | 7,000 | 8,500 |
| Nominal Output Voltage (V) | 220/230/240 | 220/230/240 | 220/230/240 | 220/230/240 |
| Output Voltage Range (V) | 160-270 (according to local standard) | | | |
| Nominal AC Grid Frequency (Hz) | 50/60 | 50/60 | 50/60 | 50/60 |

| Technical Parameters | GW5000-MS-30 | GW6000-MS-30 | GW7000-MS-30 | GW8500-MS-30 |
|--|---|---------------|---------------|---------------|
| AC Grid Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Max. Output Current (A)*3 | 24.0 | 28.7 | 33.5 | 40.7 |
| Max. Output Fault Current(peak and duration) (A) | 56.5 | 56.5 | 77 | 94 |
| Inrush Current(peak and duration) (A) | 50 | 50 | 50 | 50 |
| Nominal Output Current (A)*4 | 21.8 | 26.1 | 30.5 | 37.0 |
| Power Factor | ~1 (Adjustable from 0.8 leading to 0.8 lagging) | | | |
| Max. Total Harmonic Distortion | <3% | | | |
| Maximum Output Overcurrent Protection (A) | 56.5 | 56.5 | 77 | 94 |
| Efficiency | | | | |
| Max. Efficiency*5 | 97.8% | 97.8% | 97.7% | 97.9% |
| European Efficiency*6 | 97.2% | 97.2% | 97.1% | 97.3% |
| Protection | | | | |
| PV String Current Monitoring | Integrated | | | |
| DC Insulation Resistance Detection | Integrated | | | |
| Residual Current Monitoring | Integrated | | | |
| DC Reverse Polarity Protection | Integrated | | | |
| Anti-islanding Protection | Integrated | | | |
| AC Overcurrent Protection | Integrated | | | |
| AC Short Circuit Protection | Integrated | | | |
| AC Overvoltage Protection | Integrated | | | |
| DC Switch | Integrated | | | |
| DC Surge Protection | Type III(Type II Optional) | | | |
| AC Surge Protection | Type III(Type II Optional) | | | |
| AFCI | Optional | | | |

| Technical Parameters | GW5000-MS-30 | GW6000-MS-30 | GW7000-MS-30 | GW8500-MS-30 |
|--|--------------------------------|--------------|--------------|--------------|
| Rapid Shutdown | Optional | | | |
| Remote Shutdown | Optional | | | |
| Power Supply at Night | Optional | | | |
| General Data | | | | |
| Operating Temperature Range (°C) | -25~60 | | | |
| Relative Humidity | 0~100% | | | |
| Max. Operating Altitude (m) | 4000 | | | |
| Cooling Method | Natural Convection | | | |
| User Interface | LED, LCD (Optional), WLAN+APP | | | |
| Communication | WiFi,RS485 or LAN(Optional) | | | |
| Communication Protocols | Modbus-RTU (SunSpec Compliant) | | | |
| Weight (Kg) | 19.0 | | | |
| Dimension (W×H×Dmm) | 441×507×210 | | | |
| Noise Emission (dB) | < 30 | | | |
| Topology | Non-isolated | | | |
| Self-consumption at Night (W) | < 1 | | | |
| Ingress Protection Rating | IP66 | | | |
| Anti-corrosion Class | C4 | | | |
| DC Connector | MC4(2.5~4mm2) | | | |
| AC Connector | AC connector | | | |
| Environmental Category | 4K4H | | | |
| Pollution Degree | III | | | |
| Overvoltage Category | DC II / AC III | | | |
| Protective class | I | | | |
| The Decisive Voltage Class (DVC) | PV: C AC: C Com: A | | | |
| Active Anti-islanding Method | AFDPF + AQDPF ^{*7} | | | |
| Country of Manufacture(Only for Australia) | China | | | |

| Technical Parameters | GW9900-MS-30 | GW10K-MS-30 | GW7000-MS-C30 | GW8000-MS-C30 |
|--|---------------------------------------|-------------|---------------|---------------|
| Input | | | | |
| Max.Input Power (W) | 15,500 | 15,500 | 10,850 | 12,400 |
| Max.Input Voltage (V) | 600 | 600 | 600 | 600 |
| MPPT Operating Voltage Range (V) | 40~560 | 40~560 | 40~560 | 40~560 |
| MPPT Voltage Range at Nominal Power (V) | 170~500 | 170~500 | 180~500 | 205~500 |
| Start-up Voltage (V) | 50 | 50 | 50 | 50 |
| Nominal Input Voltage (V) | 360 | 360 | 360 | 360 |
| Max. Input Current per MPPT (A) | 20 | 20 | 20 | 20 |
| Max. Short Circuit Current per MPPT (A) | 25 | 25 | 25 | 25 |
| Max.Backfeed Current to The Array (A) | 0 | 0 | 0 | 0 |
| Number of MPP trackers | 3 | 3 | 2 | 2 |
| Number of Strings per MPPT | 1 | 1 | 1 | 1 |
| Output | | | | |
| Nominal Output Power (W) | 9,990 | 10,000 | 7,000 | 8,000 |
| Nominal Output Apparent Power (VA) | 9,990 | 10,000 | 7,000 | 8,000 |
| Max. AC Active Power (W) ^{*1*9} | 9,990 | 10,000 | 7700 | 8800 |
| Max. AC Apparent Power (VA) ^{*2*8} | 9,990 | 10,000 | 7700 | 8800 |
| Nominal Power at 40°C (W)(Only for Brazil) | - | 10,000 | 7,000 | 8,000 |
| Max Power at 40°C (including AC overload) (W)(Only for Brazil) | - | 10,000 | 7,000 | 8,000 |
| Nominal Output Voltage (V) | 220/230/240 | 220/230/240 | 220/230 | 220/230 |
| Output Voltage Range (V) | 160~270 (according to local standard) | | | |
| Nominal AC Grid Frequency (Hz) | 50/60 | 50/60 | 50/60 | 50/60 |

| Technical Parameters | GW9900-MS-30 | GW10K-MS-30 | GW7000-MS-C30 | GW8000-MS-C30 |
|---|---|--------------------|---------------|---------------|
| AC Grid Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Max. Output Current (A) ^{*3} | 43.4 ^{*8} | 43.5 ^{*8} | 33.5 | 38.3 |
| Max. Output Fault Current(peak and duration) (A/ms) | 94 | 94 | 77 | 77 |
| Inrush Current(peak and duration) (A) | 50 | 50 | 50 | 50 |
| Nominal Output Current (A) ^{*4} | 43.4 ^{*8} | 43.5 ^{*8} | 31.9 | 36.4 |
| Power Factor | ~1 (Adjustable from 0.8 leading to 0.8 lagging) | | | |
| Max. Total Harmonic Distortion | <3% | | | |
| Maximum Output Overcurrent Protection (A) | 94 | 94 | 77 | 77 |
| Efficiency | | | | |
| Max. Efficiency ^{*5} | 97.9% | 97.9% | 97.6% | 97.6% |
| European Efficiency ^{*6} | 97.3% | 97.3% | 97.0% | 97.0% |
| Protection | | | | |
| PV String Current Monitoring | Integrated | | | |
| PV Insulation Resistance Detection | Integrated | | | |
| Residual Current Monitoring | Integrated | | | |
| PV Reverse Polarity Protection | Integrated | | | |
| Anti-islanding Protection | Integrated | | | |
| AC Overcurrent Protection | Integrated | | | |
| AC Short Circuit Protection | Integrated | | | |
| AC Overvoltage Protection | Integrated | | | |
| DC Switch | Integrated | | | |

| Technical Parameters | GW9900-MS-30 | GW10K-MS-30 | GW7000-MS-C30 | GW8000-MS-C30 |
|----------------------------------|--------------------------------|-------------|---------------|---------------|
| DC Surge Protection | Type III(Type II Optional) | | | |
| AC Surge Protection | Type III(Type II Optional) | | | |
| AFCI | Optional | | | |
| Rapid Shutdown | Optional | | | |
| Remote Shutdown | Optional | | | |
| PID Recovery | Optional | | | |
| Power Supply at Night | Optional | | | |
| General Data | | | | |
| Operating Temperature Range (°C) | -25~60 | | | |
| Relative Humidity | 0~100% | | | |
| Max. Operating Altitude (m) | 4000 | | | |
| Cooling Method | Natural Convection | | | |
| User Interface | LED, LCD (Optional), WLAN+APP | | | |
| Communication | WiFi,RS485 or LAN(Optional) | | | |
| Communication Protocols | Modbus-RTU (SunSpec Compliant) | | | |
| Weight (Kg) | 19 | 19 | 18 | 18 |
| Dimension (W×H×Dmm) | 441×507×210 | | | |
| Noise Emission (dB) | <30 | | | |
| Topology | Non-isolated | | | |
| Self-consumption at Night (W) | <1 | | | |
| Ingress Protection Rating | IP66 | | | |
| Anti-corrosion Class | C4 | | | |
| DC Connector | MC4(2.5-4mm²) | | | |
| AC Connector | AC connector | | | |
| Environmental Category | 4K4H | | | |
| Pollution Degree | III | | | |
| Overvoltage Category | DC II / AC III | | | |
| Protective class | I | | | |

| Technical Parameters | GW9900-MS-30 | GW10K-MS-30 | GW7000-MS-C30 | GW8000-MS-C30 |
|--|-----------------------------|-------------|---------------|---------------|
| The Decisive Voltage Class (DVC) | PV: C AC: C Com: A | | | |
| Active Anti-islanding Method | AFDPF + AQDPF ^{*7} | | | |
| Country of Manufacture(Only for Australia) | China | | | |

*1:For Brazil Max. AC Active Power (W) GW7000-MS-30 and GW7000-MS-C30 is 7000,GW8000-MS-C30 is 8000,GW8500-MS-30 is 8500

*2:For Brazil Max. AC Apparent Power (VA) GW7000-MS-30 and GW7000-MS-C30 is 7000,GW8000-MS-C30 is 8000,GW8500-MS-30 is 8500

*3:For Brazil Max. Output Current (A) GW7000-MS-30 and GW7000-MS-C30 is 33.5,GW8000-MS-C30 is 38.3,GW8500-MS-30 is 40.7,GW10K-MS-30 is 45.5

*4:For Brazil Nominal Output Current (A) GW7000-MS-30 and GW7000-MS-C30 is 31.9,GW8000-MS-C30 is 36.4,GW8500-MS-30 is 38.7,GW10K-MS-30 is 45.5

*5:For Brazil Max. Efficiency GW7000-MS-30 is 97.5%,GW8500-MS-30 is 97.8%,GW10K-MS-30 is 97.8%,GW7000-MS-C30 and GW8000-MS-C30 is 97.5%

*6:For Brazil European Efficiency GW7000-MS-30 is 97.0%,GW8500-MS-30 is 97.2%,GW10K-MS-30 is 97.2%,GW7000-MS-C30 and GW8000-MS-C30 is 97.0%

*7:AFDPF: Active Frequency Drift with Positive Feedback, AQDPF: Active Q Drift with Positive Feedback

*8:For where the Nominal Output Voltage (V) is 220,Max. Output Current (A) & Nominal Output Current (A) GW10K-MS-30 is 45.5, GW10K-MS-30 is 45.

*9:For Chile Max. AC Active Power (W) & Max.Output Apparent Power(VA) GW5000-MS-30 is 5000, GW6000-MS-30 is 6000, GW7000-MS-30 is 7000, GW8500-MS-30 is 8500, GW10K-MS-30 is 10000



Official Website

GoodWe Technologies Co.,Ltd.

 No. 90 Zijin Rd., New District, Suzhou, 215011, China

 www.goodwe.com

 service@goodwe.com



Contact Information